

ADJUSTING YOUR OUTFITTING

Moving your seat forwards or backwards



1. Undo the two knob nuts located at the front and back of the seat pan.



2. Loosen the hip pad straps at the buckles situated between the seat cradle and the shell of the kayak.



3. Lift and move the seat to your desired position and fasten the hip pad straps and the knob nuts.

Foam Foot Blocks



These foot blocks fit together as shown and goes into the bow of the Dope, Nemesis and Element to support your feet.



Thigh Braces



Move the thigh braces on both sides backwards or forwards by unscrewing only the two screws at the top, as shown.



Thigh Brace Foam Pieces



The extra thigh brace foam pieces can be glued underneath the thigh braces with contact adhesive, if needed, for a comfortable fit.



Hip Pad Shims



The hip pad shims go in-between the hip pads and the black backing plates to maximize hip stability.



Patella (knee cap) Pads



The patella pads are glued to the shell of the kayak with contact adhesive where your knees touch the inside of the boat.



Foot Block Rails



The foot blocks can be adjusted by undoing the knob nuts and moving the aluminium rails backwards or forwards.

